



Leg Extension Kit

INSTRUCTIONS FOR INSTALLATION

1. Remove all of the parts from the box. It might help to turn the wheel on it's side.
2. Remove the caps from the bottom of the pipe legs on the wheel.
3. Place the larger end of the aluminum bracket as far as it will go onto the wheel leg. Tighten the wheel leg set screw and repeat for each leg.
4. Insert the extension leg into the proper height and tighten the extension lex set screw. Repeat for each extension leg.
5. Stand the wheel back to it's upright position.
6. Readjust the height of each leg individually as needed.

